













Chart for choosing the right tap

3	3	3	4	3-4	3-4	3-4	3-4	3-4	3-4	3-4	3-4
C 2-3 thr.	C 2-3 thr.	C 2-3 thr.		C 2-3 thr.	C 2-3 thr.	C 2-3 thr.	C 2-3 thr.	C 2-3 thr.	C 2-3 thr.	C 2-3 thr.	C 2-3 thr.
F 7842 F 7862	F 7842/3	F 7842/4	F 7842/7	F 7842/9	F 7843 F 7863	F 7843/2 F 7863/2	F 7843/22	F 7843/3 F 7863/3	F 7843/4 F 7863/4	F 7843/44	F 7843/5
F 7909					F 7910			F 7888/3	F 7888/4		
F 7919					F 7920						
F 7927 F 7930					F 7928 F 7931						
F 7934					F 7935 F 7938						
4230 6030	4235	4255	—	4040/78	4040 6040	4045 6045	4340	4245 6245	4345 6345	4345/80 6345/80	4365
											
0 - E	0 - E	0 - E	0 - E	Vaporised 0 - E	0 - E	0 - E	FUTURA coat. D MKS	0 - E	0 - E	TIN coating 0 - E	Vaporised 0 - E
15-20		15-20	15-20	10-20	15-20	15-20	10-15 20-50 10-15 20-50			30-50 30-50	
	5-10 3-6							5-10 3-6		10-20	
		6-10							6-10	10-20	6-10
		6-10							6-10	10-20	6-10
						15-20	15-30 20-50			20-50	
						15-20	15-30 20-50			20-50	
		20-40					20-50		20-40	30-50	
		20-40	20-30				20-50		20-40	30-50	
											20-30
								20-30		20-30	

Continues on next page